



Secret Fixed Capping

INSTALLATION GUIDE



Our Secret Fixed System is made from a high quality Aluminium which effectively protects masonry from rain, snow and moisture.

The Secret Fixed System wall cover allows a colorful accentuated Roof edge by using subtle color choices to match the architecture. There is a broad spectrum of RAL colors to choose from.

All products are manufactured from Polyester Powder coated Aluminium.

The system includes all industrially prefabricated special shaped parts, such as welded corners, head pieces, Upstands etc. and the Secret Fix holder system. The system also allows for the removal of components if and when required as per end users requirements.



INSTALLATION GUIDE

Secret Fixed Capping

1. Any welded Corners are to be placed and aligned. Ensure overhang to front and back are as per design/drawings.
2. Welded Corner is to be marked for positioning of the Secret Fix pieces.
3. One half Secret Fix piece is to be placed at the corner (See Fig. 1)
4. There is then a full Secret Fix Piece needed at the end of each welded corner. These pieces are fixed with their centre line matching the end of the Welded Corner.
5. Once all corner Secret Fix fixing points have been placed the remainder of the capping's Secret Fix pieces should be placed along the wall before being mechanically fixed. This is to ensure that there are no issues with poor masonry, dirt etc along the wall.
6. Overhang and fall to be built up on wall if required.
7. The Secret Fix fixings should be placed as per KYTUN's drawings. This should be a minimum of 1 per 1m length of coping.
8. If necessary, place a support under the Secret Fix's and fix the gradient. Again, this should be consistent with the drawings.
9. Secret Fix pieces are to be screwed in twice, once on each side of the rubber seals on both the inside and outside of the piece.
10. Welded Corners are to be placed on the Secret Fix's and snapped into place. There should be a very noticeable click into place. (See Fig. 2)
11. The straight lengths are then to be placed as per the drawings along the lengths of the wall. Each length should start and finish at the mid-point of a Secret Fix piece. An audible click should be heard when placing every length. (See Fig. 3)
12. When the final piece has been installed a final check should be carried out that all lengths are fully engaged with the CLIP-IT piece and in particular the "snap" section.



Fig. 1



Fig. 2



Fig. 3

